


《F9 key to restore the system SOP》

- 1.The latest OEM OS is required to support it;
- 2.BIOS support F9 is required to enter the Recovery UI.
- 3.Press the "F9" key when booting or rebooting to enter recovery mode.
- 4.Select "Troubleshoot" and select " Recovery Tool" to automatically reinstall the system according to the following figure(If the system is damaged, you need to back up the data through the PE system in advance. After entering the recovery mode again, restore the factory system in this way).



- 5.Select " Recovery Tool", pay attention to be sure to back up the data in advance, this operation will lose all partition data.

