


T40 Restore Factory Settings


Note: After the following steps are completed, all the data in the partition where the system is located (usually the C drive) will be deleted, so please make sure there is no important data before you operate;

1) T40 power on, after the Windows interface appears (Windows desktop or Windows OOBE wizard interface), long press the power on button until the power on indicator light goes out; then again this short press the power on button to power on the T40, and so on after entering the Windows interface (Windows desktop or Windows OOBE wizard interface), long press the power on button until the The power on indicator light is off; finally press the power on button again to power on the T40, then it will enter the recovery environment as shown in step 2; power on the T40, after the Windows interface appears (Windows desktop or Windows OOBE wizard interface), long press the power on button until the power on indicator light is off; then press the power on button again to power on the T40, then enter the Windows interface (Windows desktop or Windows OOBE wizard interface), long press the power on button until the power on indicator light is off. (After entering the Windows interface (Windows desktop or Windows OOBE wizard interface), press and hold the power on button until the power on indicator light goes off; finally press the power on button again to power on the computer, and then it will enter the recovery environment shown in step 2);




T40 power-on indicator

2) After entering the recovery mode, just follow the step-by-step operation as shown below;



Troubleshoot



Reset this PC

Lets you choose to keep or remove your personal files, and then reinstalls Windows.



Reinstall

Reset to factory settings. Warning: User data and apps will be removed.



Advanced options

Reset this PC

Choose an option



Keep my files

Removes apps and settings, but keeps your personal files.



Remove everything

Removes all of your personal files, apps, and settings.

Reset this PC

How would you like to reinstall Windows?

If your connection is metered charges may apply. Cloud download can use more than 4 GB of data.



Cloud download

Download and reinstall Windows



Local reinstall

Reinstall Windows from this device

Reset this PC

Your PC has more than one drive. Do you want to remove all files from all drives?



Only the drive where
Windows is installed



All drives

Reset this PC

Do you want to fully clean your drive? When you remove your files, you can also clean the drive so that the files can't be recovered easily. This is more secure, but it takes much longer.



Just remove my files
Use this if you're keeping your PC.



Fully clean the drive
Use this if you'll recycle the PC. This can
take several hours.

Reset this PC

Are you ready to reset this device? This can't be undone.
Make sure your device is plugged in. This may take a while.

Resetting will:


- Remove all personal files and accounts on this device
- Remove any changes made to settings
- Remove all apps and programs that didn't come with this PC
- Reinstall Windows from this device

Reset

Cancel

Click on the [Reset] button to begin the reset process

This process will take a long time (may take 2-3 hours), please be patient!



Finally, go to the OOB screen and follow the wizard to recreate the account;